

LANE GUARD Pavement Protection Systems

Pre-installation cleanup suggestions

Grease Dumpster Area

Prior to installing your [Omni Containment Systems Lane Guard grease spill containment system](#), the following procedure will help you do your part in reducing waste grease and oils from entering the public storm drains.

1. Remove large white absorbent boom from plastic bag and create a barrier to prevent grease contaminated clean-up water from entering the drain.



2. Sweep and scrape up as much of the grease build up and spill from area of installation.
3. Wet all surfaces containing residual grease and stain build up from area where Lane Guard is to be installed.
4. Apply Grease Away granules to the wet, stained surface. Allow about 15 minutes for Grease Away to neutralize the treated area (Generally the treated area will lighten several shades in color once the process is complete).



5. Clean area with high pressure hose or power washer, move waste water toward drain blocked by the absorbent boom.
6. Dispose of grease saturated boom in supplied bag.